

# HOW TO ATTACH THE YOKE MOUNT

---



## STEP 1

Align the yoke with the mounting points on the side of the Titan



## STEP 2

Secure using bolts and included Allen key.



## STEP 3

The Yoke can then be mounted onto a lighting stand. We recommend using a C-Stand with sandbags.

Recommended stand: The Titan X1 is compatible with RL-LIGHTSTAND as well as c-stands, whilst the Titan X2 requires a Junior to Baby adapter (RL-CSTAND-J2B) if mounting onto a c-stand 16mm Baby spigot. We recommend using a sandbag to provide additional support.

The Titan X1 can either be mounted onto a 16mm Baby Spigot, or, by removing the tensioner, The 16mm TVMP socket becomes a 28mm Junior stud. Titan X2 is equipped with a 28mm Junior stud. Rotolight also sell a 28mm Junior socket to 16mm Baby stud adapter, available from our accessories page.

# HOW TO ATTACH THE SWAN NECK

---



## STEP 1

Align the pins on the swan neck with the matching holes on the rear plate of the Titan.



## STEP 2

Rotate the swan neck clockwise until it clicks into place. Use the tension knob to adjust angle and position as required, taking care to support the weight of the unit when making any adjustments.



## STEP 3

To remove, firstly get a good hold of the Lighting fixture, then pull the quick release knob...etc. The Fixture will become loose rather quickly, so take care not to drop it.